## Christy's \*



ADDITIONAL INFORMATION	
Surface Preparations and Finishing	Application temperature $41^{\circ}-86^{\circ}F$ (5 – $30^{\circ}C$ ) (environment and substrate).
Appearance	Colourless to pale amber liquid – once applied to surface.
Packaging	• 1 x 1.5 oz Adhesive + MitrePen • 3 x 1.5 oz Adhesive + MitrePen
Shelf Life	In unopened original packaging between 41°–77°F (5° – 25°C) shelf-life till 24 months after production date, stored in a dry place

## MITREBOND PEN

MitrePen is a quick and clean way to apply MitreBond Activator.

- Precision marker rather than a spray.
- Prevents the staining caused by overspray.
- MitrePen covers the same area as 3 x 200ml activator sprays.
- Cures MitreBond in 10 seconds.

## **Directions of Use**

- Ensure both surfaces to be joined are clean cut and free from oil or grease.
- Apply MitreBond adhesive to one side of the joint.
- Apply MitrePen activator to the other side of the joint.
- Quickly bring the two sides into line and firmly press together, hold for 10 seconds.

## **Health & Safety**

- Keep in a cool well-ventilated area away from sources of ignition.
- Keep away from children at all times.
- Keep containers sealed.
- Use in a well-ventilated area.
- Avoid contact with skin and eyes.

For further information, please read the product SDS.

Refer to Safety Data Sheet ("SDS") for safety precautions, first aid, storage, handling, transportation, and disposal information.

IPS Corporation 455 W. Victoria St., Compton, CA 90220 (800) 888-8312 www.tchristy.com